

## Container Handler

Used Container Handler Portland - Container handlers, also known as cargo ships and container ships transport their load in a large intermodal container. This type of shipping is called containerization and it is a specific kind of freight transport that carries non-bulk types of seagoing cargo. The capacity of container ships is measured in units equivalent to twenty-foot equivalent loads. The majority of typical loads consist of a mix of 40-foot containers and 20-foot containers. Approximately ninety percent of non-bulk cargo across the globe is transported by container ships. These ships are one of the main oil tanker rivals due to their size as one of the biggest sea-worthy ships. Dry cargo is categorized into two main types: break-bulk cargo and bulk cargo. Coal and grain are considered to be bulk cargo items. They are typically transported in their raw form within the hull of the ship, free from packages in immense volume. Break-bulk cargo items normally consist of manufactured goods that are transported in packages. Before containerization was invented in the 50s, break-bulk items were loaded, secured and unlashd one item at a time. Grouping cargo into containers allows for 1000-3000 cubic feet of cargo to be simultaneously moved once every container has been secured with standardization techniques. Overall efficiency has largely increased with break-bulk cargo shipping. It is estimated that shipping time has been reduced by eighty-four percent and costs have been reduced by approximately thirty-five percent. More than ninety percent of non-bulk items were recorded as being transported in containers in 2001. The first cargo ships were born in the 1940s as redesigns from World War II tankers. Cargo ships do not use individual dividers, holds or hatches that are a part of traditional container ships. The hull of the container ship is similar to a sizeable warehouse that uses vertical guide rails to divide the area into cells. The cargo in the containers is held by these specially designed cells. Most cargo ships are designed from steel but additional materials such as plywood, fiberglass and wood are used. Designed to be completely transferred to and from trains, semi-trailers, trucks, coastal carriers and more, there is a variety of container types that are categorized by their function and size. The entire shipping industry has been revolutionized by containerization, although, it did not start out in the easiest manner. Initially, ports, railway companies and shippers were concerned regarding the extensive costs that came with constructing infrastructure, ports and railways required to accommodate the cargo ships and transporting items with rail and roads. Various trade unions were skeptical about huge job loss with dock and port workers based on the assumption that containers would eliminate numerous cargo handling manual jobs among ports. Approximately ten years of legal battles occurred prior to container ships began international service. A container liner service from the Dutch city of Rotterdam to the USA first started in 1966, soon to change world trade and shipping across the globe. Container ships only take a few hours to be loaded and unloaded, compared to the days a traditional cargo vessel required. Cutting labor finances and shortened shipping times between ports has been hugely successful. It only takes a few weeks to deliver items from India to Europe and vice versa, whereas it used to take months previously. Overall, there is less damaged cargo thanks to less physical handling and reduced cargo shifting due to properly securing loads. Before shipping, containers are closed and only opened after they arrive at their new location to prevent theft and damage. Container ships have reduced shipping time and lessened shipping expenses, resulting in enhanced international trade growth. Cargo that used to arrive in bales, crates, bags, cartons or barrels now arrives in containers sealed from the factory. Scanning machines work with computers to trace the product code on the contents. Technological advancements have enabled this accurate tracking system to be precise within fifteen minutes on arrival of a two-week voyage. Manufacturing times and delivery have been greatly enhanced with these advancements. Raw materials show up in sealed containers from factories in under an hour prior to being used in the manufacturing industry; resulting in fewer inventory expenses and greater accuracy. Boxes are provided by shipping companies to the exporters to facilitate loading merchandise. They are delivered into the docks by rail or road or a combination of both to be loaded onto container ships. Before containerization,

it would take large groups of men and many hours fitting cargo items into different holds. The ship relies on cranes either on the pier or installed on board to organize the containers accurately. More containers can be loaded onto the deck after the hull is loaded. An efficient design has been a huge priority for shipping containers. Containers may travel on break-bulk vessels. However, cargo holds that have been dedicated to container ships have been carefully built to speed up the loading and unloading process and designed to keep containers secure while traveling the ocean. There is a sophisticated hatch design to allow openings from the main deck to reach the cargo hold locations. These openings flow along the whole cargo hold area and are surrounded by the hatch coaming which is a raised steel structure. There are hatch covers located on top of the hatch coamings. Wooden boards and tarps initially covered the hatches and held the battens secure until the 50s. Hatch covers are made of secure metal plates and cranes are used to lift them on and off of the ship. There are other hatch models that rely on articulated mechanisms that use strong hydraulic rams for opening and closing. Cell guides are another main component within container ship design. The cell guides are vertical pieces constructed of strong metal that is attached to the cargo hold within the ship. They work by guiding containers into particular rows while loading and help to support items during travel. The container ship design relies on cell guides so much that organizations as the United Nations Conference on Trade and Development use them to differentiate between regular break-bulk cargo ships and container ships. There is a system used in cargo plans consisting of three dimensions to outline a container's position aboard the ship. The first coordinate is the bay which begins at the front of the ship and increases aft. The tier is the second coordinate, with the initial tier staring at the bottom of the cargo holds with the second, tier situated on top of the first and continuing on. The third coordinate is found in the third row. Rows are situated on the ship's port side have even numbers while those found starboard have odd numbers. Rows found along the centerline are given lower numbers and these numbers increase for slots situated further from the center. Container handlers carry 20, 40 and 45 foot containers. The biggest sizes only fit above the deck. The forty-foot containers comprise most of the load or roughly 90% of container shipping. Roughly 90% of the freight in the world is delivered via container shipping. Approximately eighty-percent of global freight is shipped via forty-foot containers.